

DART SERVICE INSTRUCTION

TO AMEND INSTALLATION INSTRUCTIONS IIN-D412-702 REV. E
& INSTRUCTIONS FOR CONTINUED AIRWORTHINESS ICA-D412-702 REV. 3
REF TC STC SH04-7 & FAA STC SR01997NY

D412-702-051A/-051B/-052A/-052B 1-man 3-point shoulder harness kits are available for the outboard seats of the 5-man forward facing bench in Bell 205/212/214/412 model aircraft. Install as follows. The parts list is provided on sheet 3. The D412-702-051A/-051B/-052A/-052B kits should be maintained per ICA-D412-702 as applicable.

- 1) Remove existing lap belt and/or shoulder harness installations from the outboard seats of the 5-man forward facing bench per the applicable maintenance manual or ICA. If the Dart D412-702-011/-021/-013/-023 shoulder harness kits are already installed, do not remove the D3195-043 brackets from the stanchion posts. Refer to Detail B of *Figure 1*. Ensure that the D3268-1 placard is not removed from the aircraft.
- 2) Disconnect the tops of the aircraft stanchion posts from the aircraft roof per the Aircraft Maintenance Manual. It may be necessary to disconnect the bases of the posts as well.
- 3) Position a D3542-1 bracket over the top of each post as shown in *Figure 1, Detail A*. Install the D412-702-107A/-107B harness assembly on the bracket on the LH stanchion post at a forward angle of 45° using the hardware shown in *Detail A*. Install the D412-702-109A/-109B on the bracket on the RH stanchion post at a forward angle of 45°.
- 4) Remove the OEM 205-070-742-001 blocks from behind the OEM 205-070-743-001 supports and discard the fasteners. Install the D3610-041 bracket and D3571-3 guide with the D3618-1 cap on each post as shown in *Detail B*. Trim the D3618-1 cap as needed to fit. Torque the AN4 bolts to 50-70 in-lbs (5.6-7.9 N-m).
- 5) Feed the shoulder belts through the guides so that the K6.2 clips are between the guides and the buckles as shown in *Figure 1*. Clip the lap belts and buckles onto the OEM seat belt rings as shown in *Detail C* and engage the belts in the buckles. Orient the harness assemblies and the D3571 guides so that the shoulder belts have a straight path to the buckles as shown in *Figure 1*. Torque the #10 fasteners to 20-25 in-lbs (2.3-2.8 N-m). Ensure that the that the D3569-1/-2/-3 decals on the buckles face outward.
- 6) At the customer's option, secure the end fittings of the lap belts using MS20995C41 lockwire per AC43.13-1B Chapter 7 Section 7 or install an MS24665 cotter pin.











FIGURE 1. D412-702-051A/-051B/-052A/-052B INSTALLATION

CANADA DEPARTMENT OF TRANSPORT AIRCRAFT CERTIFICATION BRANCH DAO # 01-O-01	
APPROVED	
BY:	
D. SHEPHERD (DE # 02)	
DATE:	07.11.21
CERT. NO.:	SH04-7
ISSUE NO.:	3

A	NEW ISSUE	LE	07.11.21
REV.	DESCRIPTION		BY DATE
DESIGN		DART AEROSPACE LTD	
DRAWN		HAWKESBURY, ONTARIO, CANADA	
CHECKED		DRAWING NO.	REV. A
MFG. APPR.	N/A	DSI 9397	SHEET 1 OF 3
APPROVED		TITLE	SCALE
DE APPR.		SHOULDER HARNESS KITS	NTS
DATE	07.11.21	COPYRIGHT © 2007 BY DART AEROSPACE LTD	
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.			



CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-O-01

APPROVED

BY: *[Signature]*
D. SHEPHERD (DE # 02)

DATE: 07.11.21
CERT. NO.: SH04-7
ISSUE NO.: 3

DESIGN	LE	DART AEROSPACE LTD	
DRAWN	LE	HAWKESBURY, ONTARIO, CANADA	
CHECKED	J	DRAWING NO.	REV. A
MFG. APPR.	N/A	DSI 9397	SHEET 2 OF 3
APPROVED	140	TITLE	SCALE
DE APPR.	SA	SHOULDER HARNESS KITS	NTS
DATE	07.11.21	COPYRIGHT © 2007 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.	



QTY -051A	QTY -052A	QTY -051B	QTY -052B	Part Number	Description
X				D412-702-051A	1-Man 3-Point LH Shoulder Harness Kit
	X			D412-702-052A	1-Man 3-Point RH Shoulder Harness Kit
		X		D412-702-051B	1-Man 3-Point LH Shoulder Harness Kit
			X	D412-702-052B	1-Man 3-Point RH Shoulder Harness Kit
1				D412-702-107A	HARNESS ASSEMBLY
1*				D3573-3	ADAPTER
1*				D3579-042	SHOULDER HARNESS
1*				K6.2	CLIP
4*				MS24693S272	SCREW
4*				AN960JD10LL	WASHER
4*				MS21042L3	NUT
	1			D412-702-109A	HARNESS ASSEMBLY
	1*			D3573-3	ADAPTER
	1*			D3579-041	SHOULDER HARNESS
	1*			K6.2	CLIP
	4*			MS24693S272	SCREW
	4*			AN960JD10LL	WASHER
	4*			MS21042L3	NUT
		1		D412-702-107B	HARNESS ASSEMBLY
		1*		D3573-3	ADAPTER
		1*		D3579-046	SHOULDER HARNESS
		1*		K6.2	CLIP
		4*		MS24693S272	SCREW
		4*		AN960JD10LL	WASHER
		4*		MS21042L3	NUT
			1	D412-702-109B	HARNESS ASSEMBLY
			1*	D3573-3	ADAPTER
			1*	D3579-045	SHOULDER HARNESS
			1*	K6.2	CLIP
			4*	MS24693S272	SCREW
			4*	AN960JD10LL	WASHER
			4*	MS21042L3	NUT
1	1	1	1	D3542-1	BRACKET
1	1	1	1	D3571-3	GUIDE
1	1	1	1	D3610-041	BRACKET
1	1	1	1	D3618-1	CAP
2	2	2	2	AN4-10A	BOLT
1	1	1	1	AN4-44A	BOLT
1	1	1	1	MS24693S274	SCREW
3	3	3	3	AN960JD416	WASHER
2	2	2	2	AN960JD416L	WASHER
3	3	3	3	MS21042L4	NUT

*Denotes that part is included with assembly above

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-O-01

APPROVED
BY: 
D. SHEPHERD (DE # 02)

DATE: 07.11.21
CERT. NO.: SH04-7
ISSUE NO.: 3

DESIGN		DART AEROSPACE LTD	
DRAWN		HAWKESBURY, ONTARIO, CANADA	
CHECKED	N/A	DRAWING NO.	REV. A
MFG. APPR.		DSI 9397	SHEET 3 OF 3
APPROVED		TITLE	SCALE
DE APPR.		SHOULDER HARNESS KITS	NTS
DATE	07.11.21	COPYRIGHT © 2007 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.	